

1
3
15
2
22
4
5
13
11
25
8
7
16
12
27
9
10
17
18
6
19
24
29
30
31
28

A	333/E2344	Tool ecoMax engine list of engine tools	1
1	892/00292	Tool filter remover > No Longer Available	1
2	892/00041	Tool bore deglazing	1
3	892/01146	Tool fitting core plug	1
4	892/01147	Tool crankshaft turning < Supersession	1
5	892/01148	Tool timing pin crank & cam	1
6	892/01149	Template oil pan sealant pressed sumps only	1
6	892/12354	Tool template sump T4 sealant application cast sumps only (excavators)	1
7	892/01156	Tool rear crankshaft oil seal fitting	1
8	892/01158	Tool mandrel rear oil seal	1
9	892/12346	Tool injector seals fitting T4	1
10	892/12347	Tool dummy injector T4	1
11	892/01150	Tool location pin sump pan	1
12	892/12348	Tool injector sleeve fitting/removal T4	1
13	892/01152	Tool fitting, valve stem seal	1
14	892/01154	Tool remover f.i.p gear cover	1
15	892/01155	Tool removal f.i.p gear	1
16	892/01157	Tool front crankshaft seal fitting	1
17	892/12349	Tool template sealant G/C to F/W housing T4	1
18	892/01176	Template sealant gearcase to block	1
19	892/12356	Template sealant block to bea	1
20	892/12350	Kit FIE leak off test < Supersession	1
21	993/70111	Wrench setting	1

22	331/27987	Socket snap-on	1
23	892/12351	Tool WRENCH T4 SENSOR WRENCH T4 SENSOR	1
24	892/12359	Kit cap FIE T4 *T4F compatible also.*	1
25	892/01381	Tool CCV ball/star fitting	1
26	892/01383	Tool FUEL FILTER REMOVAL FUEL FILTER REMOVAL	1
27	892/01380	Tool lash adjustment service kit	1
28	892/01382	Tool eng lft spreader bar	1
29	320/07342	Cap 6mm ID x 6mm long	1
30	320/07343	Plug injector < Supersession	1
31	320/09108	Plate base lash adjuster	1