

23
8
5
10
17
18
20
6
12
22
14
13
15
3
2
7
1
9
11
19
21
1A
1
2A
2
3A
3
5A
5
6A
6
7A
7
8A
8
9A
9
10A
10
11
12A
12
15
398002

A	128/11861	GA GAUGE PLATE heate 2CXMKIII	1
1A	701/58704	Actuator beacon switch decal *<M930431*	1
1A	701/58825	Actuator Beacon Switch Lights	1
1	701/60000	Switch Panel Beacon	1
2A	701/58752	Cover actuator arm suspension *<M930431*	1
2A	701/58842	Cover SRS Switch SoftTouch	1
2	701/60000	Switch Panel SRS	1
3	701/80357	Switch 2WS Mode 2/4WS	1
3A	817/17854	Label 2/4WS Mode	1
5A	701/58703	Cover Roadlamps Switch Decal *<M930431*	1
5A	701/58824	Decal Road Lamps Switch	1
5	701/60004	Switch Panel Road lights	1
6A	701/58705	Cover front work lights switch decal *<M930431* Excavator & Loader	1
6A	701/58826	Actuator Switch Front Worklights	1
6	701/60004	Switch Panel Front worklights	1
6	701/60016	Switch 3 position 12V German and Italian machines only	1
7A	701/58706	Cover rear working lights switch decal *<M930431*	1
7A	701/58827	Actuator Switch Rear Worklights	1
7	701/60002	Switch Panel Rear worklights	1

8A	701/58700	Cover hazard switch decal *<M930431*	1
8A	701/58821	Decal Hazard Switch	1
8	701/60005	Panel 12V 2 Position **Hazard warning**	1
9A	701/58727	Cover heater blower speed switch decal *<M930431*	1
9A	701/58837	Decal Reversing Fan switch decal	1
9	701/60016	Switch 3 position 12V **Heater**	1
10A	701/58708	Cover fog light switch decal *<M930431*	1
10A	701/58829	Actuator Fog Light Switch	1
10	701/60000	Switch Panel **Fog light**	1
11A	701/58707	Cover wash, wipe switch decal *<M930431*	1
11A	701/58828	Actuator wash,wipe switch decal	1
11	701/60003	Switch 12V **Rear wash/wipe**	1
12A	701/58797	Actuator switch, rear horn *<M930431*	1
12A	701/58845	Cover rear horn	1
12	701/60079	Switch Panel **< Supersession** **Rear horn**	1
13	701/80184	Switch Ignition **< Supersession** *701/45502 is the weather proof cap 8030 ZTS*	1
14	:701/45501	Key Door/Ignition **< Supersession**	1
15	701/80265	Switch panel blank **With connector retention**	0
17	⃠ Not for sale	'See Remark' **Column switch See index C3**	1

18	Not for sale	'See Remark' Switch cover See index B2	1
19	715/08100	Socket 12V	1
20	Not for sale	'See Remark' Warning lights and guages See index C3	1
21	717/08600	Cover Radio Blanking Supersession >	1
22	Not for sale	'See Remark' Heater controls See index C3	1