
2026/1/20 14:03:19

JS115 [T2] > B1-4-1 TANK, DIESEL FUEL



| | | | |
|---|---|---|---|
| A | 215/11605 | G.A. FUEL TANK | 1 |
| 1 | Not for sale | Tank fuel ABI | 1 |
| 2 | :331/31152 | Cap filler with lock | 1 |
| 3 | ::701/45501 | Key Door/Ignition<br>< Supersession | 1 |
| 4 | 826/11113 | Stud Threaded M16x93<br>Secures tank | 6 |
| 5 | JSJ0042 | Spacer<br>For item 4 | 6 |
| 6 | 32/925428 | Plug Drain Valve, M20<br>Fit to tank bottom | 1 |
| 7 | JRH0083 | Strainer Fuel Filter<br>Fit in filler neck | 1 |
| 8 | JHH0120 | Gauge diesel fuel level<br>Fit to tank | 1 |
| 8-1 | Not for sale | None serviced part | 1 |
| 8-2 | Not for sale | None serviced part | 1 |
| 8-3 | Not for sale | None serviced part | 4 |
| 9 | 816/90205 | Cap Blanking 1" BSP Female<br>< Supersession | 1 |
| 10 | 716/30142 | Sender fuel level with gasket<br>Supersession ><br>Fit into tank | 1 |
| 11 | KHH0040 | Plate Shim T=0.03"<br>For item 4 | 2 |
| 12 | KHH0137 | Shim Plate<br>For item 4 | 2 |
| 13 | 1316/0301Z | Screw<br>< Supersession<br>Secures fuel sensor | 4 |

| | | | |
|---|---|---|---|
| 14 | 1420/0005Z | Washer (M5)<br>< Supersession<br>For item 13 | 4 |
| 15 | Not for sale | Sealant Liquid Packing, Gasket<br>Supersession > | 0 |
| 16 | 1371/0603Z | Nut Lock M16 | 6 |
| 17 | JHP0043 | Washer M16<br>< Supersession | 6 |