
A
18
7
6
5
13
26
27
11
17
28
26
21
23
25
1
2
8
19
15
14
8
10
9
16
28
21
27
27
26
11
17
10
14
16
15
12
26
5
4
23
18
9
11

A	459/10247	Clutch input assembly powershift < Supersession	1
1	:459/50722	Shaft input < Supersession	1
2	:904/50020	Seal Ring 35mm Dia < Supersession	4
4	:449/10002	Housing plate carrier assy 31T & 45T	1
5	:2203/1115	Circlip < Supersession	2
6	:459/50683	Gear 48T < Supersession	1
7	:449/10501	Disc Spring Splined	2
8	:828/00414	O Ring 123.5mm I/D < Supersession	2
9	:814/00345	Spring	2
10	:821/00523	Circlip	2
11	:445/12303	Washer Thrust	2
12	:823/10327	Washer Thrust (35.15mm x 60mm x 3.51mm)	1
13	:449/10003	Housing plate carrier assy 22T & 45T	1
14	:445/40203	Spring retaining	2
15	:445/40204	Baffle oil	2
16	:449/M2157	Piston Clutch < Supersession	2
17	:445/30011	Plate friction	12
18	:445/12307	Plate Counter < Supersession	12
19	:828/00224	O Ring 39.7mm I/D X 3.53mm	2
21	:917/02700	Bearing Needle Roller Supersession >	2

23	:445/12314	Shim plate, Toothed < Supersession A/R	0
25	:459/10171	Kit pressure plate 6mm & 6.5mm < Supersession	2
26	:445/26108	Washer Thrust (40.25mm x 60mm x 1mm) < Supersession	4
27	:917/02800	Bearing Thrust	4

Following JCB's Serviceability Review, only those items with part numbers are available to purchase for this Component. For any other items please purchase the next available parent assembly.